



www.customcargrills.com
info@customcargrills.com

customcargrills.com LLC
PO Box 90004
Grand Rapids, MI 49509
(616) 889-2985

Year: 1988-1990
Make: Chevy
Model: Cavalier Z24

INSTALLATION INSTRUCTIONS



What's in the Box: (2) Lower Bumper Mesh Grills



Tool List: None

Lower Bumper Mesh Installation:



(Tabs should be roughly here).

1. Start by orienting your inserts with the clips to the bottom.
2. Take one of the inserts and put it behind the existing opening.
3. Center the insert so that it covers all of the opening and press forward on the silver tabs in a way that they clip onto the existing grill.
4. Repeat for other side and then test their strength by gently tapping on the grill to ensure it is on correctly.

PLEASE NOTE: The instructions provided are the suggested installation method. If you feel that the installation instructions are inadequate or unsafe then please feel free to develop your own installation techniques that fit your exact needs. customcargrills.com llc is not liable for any personal or property damage resulting from our products. If you have any suggestions on how to improve our installation instructions then please email your comments to info@customcargrills.com .