



[www.customcargrills.com](http://www.customcargrills.com)  
[info@customcargrills.com](mailto:info@customcargrills.com)

customcargrills.com LLC  
PO Box 90004  
Grand Rapids, MI 49509  
(616) 889-2985

Year: 2009-2012  
Make: Ford  
Model: Mustang V6

## INSTALLATION INSTRUCTIONS



**What's in the Box:** (1) Mesh Grill Piece, (8) Ties, (1) Small Spool of Metal Wire (optional).

**Tool List:** Wire Cutters

### Upper Bumper Mesh Installation:

1. Start by opening your hood and propping your hood up. You need to remove the factory grill or gain access to behind the grill area.
2. Place the insert in the grill opening.
3. Holding the grill mesh in place, run ties through the stock grill (starting them from behind the stock grill) and the new grill. Then loop the cable tie back through an adjacent mesh diamond. Check to make sure the cable tie is going around one of the existing grill bars. The metal wire can be used an alternative for the ties if desired.
4. Secure the tie and repeat this process a few more times so that the grill is secured. We suggest a minimum of 4 ties.
5. Clip the ends of the cable ties off.
6. Replace the grill (of removed), top splash guard, & close hood.
7. To conceal any remaining parts of the cable tie on top of the mesh, it's possible to use a silver marker and brush over the tie in the areas where the mesh should be.

PLEASE NOTE: The instructions provided are the suggested installation method. If you feel that the installation instructions are inadequate or unsafe then please feel free to develop your own installation techniques that fit your exact needs. customcargrills.com llc is not liable for any personal or property damage resulting from our products. If you have any suggestions on how to improve our installation instructions then please email your comments to [info@customcargrills.com](mailto:info@customcargrills.com) .