



www.customcargrills.com
info@customcargrills.com

customcargrills.com LLC
PO Box 90004
Grand Rapids, MI 49509
(616) 889-2985

Year: 2003-2006
Make: Infiniti
Model: G35 - Sedan

INSTALLATION INSTRUCTIONS



What's in the Box: (1) Upper Mesh Grill, (16) Ties.



Tool List: N/A

Before installation you may want to shape the grill mesh to the curve of the factory grill.

Upper Bumper Mesh Installation:

Removing the stock grill



Remove 4 tabs on top that hold the grill to the frame



Take a flat head and release the top portion The pin should come right out then.



In each corner of the grill, there is a diamond shaped screw (look through the first horizontal opening in the grill). You have to turn that screw to make it look like a square (this will release the top part of the grill).



While pushing down on the latches that hold the bottom of the grill, pull the grill out.



This step will require patience and constant pulling. Be careful not to yank it out too hard, or your paint can get scratched. Just be patient, start from one end, and pull



Locate attaching points



On each side (left and right) of the bottom frame, there are 4 attaching points. That makes a total of 8 attaching points on the bottom



On the top there are 2 attaching points. The tabs came out of 4 holes, but only 2 go all the way through. Note where these are.



This picture shows the 2 attaching points on top.



Attach the cable ties on a sturdy point of the grill. This means do not tie it to the trim (see next picture). Begin by attaching the bottom of the grill. Attach from the middle, working outward.



Notice how there is extra grill on top, this is where forming the grill beforehand would have helped.



Lower hood slowly to make sure grill is attached properly. If grill bends awkwardly, re-forming the curve is necessary



Before attaching the top, trim the bottom cable ties to desired length. Notice how the cable tie is attached to a point in the grill where the diamonds are complete (not cut) and not attached to the trim. Attach the top part of the grill using the 2 holes that go all the way through.



Grill is attached, but too high, form it as needed.



Finished.





PLEASE NOTE: The instructions provided are the suggested installation method. If you feel that the installation instructions are inadequate or unsafe then please feel free to develop your own installation techniques that fit your exact needs. customcargrills.com llc is not liable for any personal or property damage resulting from our products. If you have any suggestions on how to improve our installation instructions then please email your comments to info@customcargrills.com .