



www.customcargrills.com
info@customcargrills.com

customcargrills.com LLC
PO Box 90004
Grand Rapids, MI 49509
(616) 889-2985

Year: 1995-1999
Make: Pontiac
Model: Sunfire SE

INSTALLATION INSTRUCTIONS



What's in the Box: (2) Grill Mesh Pieces, (8) Ties, (1) Small Spool of Wire.

Tool List: Wire Cutters, Torx Bit Screw Driver

1. Start by removing the black grill pieces that are held on place with a torx bit screw (sometimes an allen wrench can get them out if a torx bit is not available).
2. After they are removed, place the new grill insert over the black piece.
3. Cut 6 pieces of wire into 6" sections. Ties can be used in place of the wire if desired.
4. Simply loop the wire around the stock grill so the ends are not facing you.
5. Twist the wire tight up against the insert using your pliers.
6. Clip the ends of the wire about 3 winds up with your wire cutters.
7. The new insert enhanced grill should be installed back on the way it came off but this time. Be sure to feed the screw through the insert too.

PLEASE NOTE: The instructions provided are the suggested installation method. If you feel that the installation instructions are inadequate or unsafe then please feel free to develop your own installation techniques that fit your exact needs. customcargrills.com llc is not liable for any personal or property damage resulting from our products. If you have any suggestions on how to improve our installation instructions then please email your comments to info@customcargrills.com .